



## Simple Touch Switch Adjustment Guide

---

### How to adjust the height of the table



Press and hold the up arrow to raise the table.

Press and hold the down arrow to lower the table.

### How to calibrate the table

Calibrate at installation so legs are in sync or if legs become out of sync during operation.



Adjust the table to the lowest height.

Press the down arrow again and hold for 5–10 seconds.

The table will begin to readjust itself if necessary. Release the button once the table has stopped moving and clicking. Listen carefully; the clicks are quiet.